

Fantasea EyeDaptor G9-G10 (Cat. No. 4703)

Instruction Manual

The **EyeDaptor G9-G10** enables mounting Fantasea lens accessories that were designed for the Canon G10 Housing (WP-DC28) on the Canon G7 and G9 Housing lens ports (WP-DC11 and WP-DC21).

Compatibility

- Mounting the **BigEye Wide Angle Lens G10** (Cat. No. 5135) on either the Canon G7 or G9 Housing requires **EyeDaptor G9-G10** only, as described on the Instructions section below.
- Mounting the **SharpEye Macro Lens M67** (Cat. No. 5128) on either the Canon G7 or G9 Housing requires an additional adaptor- the **EyeDaptor G10-F67** (Cat. No. 4701), as described on the Instructions section below.



Included in the Kit

1. EyeDaptor G9-G10
2. 2 screws
3. Screwdriver

Mounting the BigEye Lens G10 on the Canon G7/G9 Housing

1. Please use the utmost care and do not use excessive force when assembling and disassembling the different lens accessories, in order not cause any damage to the products.
2. Place the **BigEye Lens G10** on a flat and protected surface, so the side that attaches to the housing lens port is facing up.
3. Hold the **EyeDaptor G9-G10** so the two adaptor wings are on the top side of the adaptor and the concaved part of the adaptor is facing up (see image #1).

4. Insert the **EyeDaptor G9-G10** into the dedicated groove of the **BigEye Lens G10**. Note that the two screw holes on the **EyeDaptor G9-G10** wings should be perfectly aligned with the two small screw holes on the **BigEye Lens G10**.
5. Insert the screws included into the dedicated screw holes on the two adaptor wings and use the screwdriver included to tighten the screws into the adaptor and the **BigEye Lens G10** (see image #2 on the following page). Tighten the screws enough in order to keep the **EyeDaptor G9-G10** fixed inside the **BigEye Lens G10**, but don't tighten it too strongly, as this might cause damage to the products.



Image #1:

Hold the EyeDaptor G9-G10 so the wings are on the top side of it



Image #2:

Tightening the screws on the two EyeDaptor G9-G10 wings (adaptor is highlighted)

6. During the dive, install the **BigEye Lens G10** with the adaptor inside by attaching the accessory lens to the housing lens port, as described on the **BigEye Lens G10** instruction manual.
7. When removing the **BigEye Lens G10** from the housing with the adaptor installed inside, it can be conveniently stored by attaching it to the **EyeGrabber G7/G9** (Cat. No. 4055), which mounts on Fantasea Flex Arms, thereby making it easily available for future use. For further information, please visit our website at www.fantasea.com/FantaseaEyes
8. After the dive, detach the accessory lens from the housing lens port, including all adaptors, and rinse all lens components in fresh water.
9. Dry and store in a safe protected place.

Mounting the SharpEye Lens M67 on the Canon G7/G9 Housing

1. Please use the utmost care and do not use excessive force when assembling and disassembling the different lens accessories, in order not cause any damage to the products.
2. It is recommended to first assemble the two adaptors together (the **EyeDaptor G10-F67** and the **EyeDaptor G9-G10**) prior to attaching them to the SharpEye Lens.
3. Place the **EyeDaptor G10-F67** on a flat and protected surface, so the side that attaches to the housing lens port is facing up and the thread is facing down.
4. Hold the **EyeDaptor G9-G10** so the two adaptor wings are on the top side of the adaptor and the concaved part of the adaptor is facing up (see image #3).
5. Insert the **EyeDaptor G9-G10** into the dedicated groove of the **EyeDaptor G10-F67**. Note that the two screw holes on the **EyeDaptor G9-G10** wings should be perfectly aligned with the two small screw holes on the **EyeDaptor G10-F67**.
6. Insert the screws included into the dedicated screw holes on the two adaptor wings and use the screwdriver included to tighten the screws into the **EyeDaptor G9-G10** and the **EyeDaptor G10-F67** (see image #4). Tighten the screws enough in order to keep the **EyeDaptor G9-G10** fixed inside the **EyeDaptor G10-F67**, but don't tighten it too strongly, as this might cause damage to the products.



Image #3:
Hold the EyeDaptor G9-G10 so the wings are on the top side of it



Image #4:
Tightening the screws on the two EyeDaptor G9-G10 wings (adaptor is highlighted)

7. Once the **EyeDaptor G9-10** has been installed inside the **EyeDaptor G10-F67**, the **SharpEye Lens M67** can be installed on the thread mount of the **EyeDaptor G10-F67** by screwing it in.

8. During the dive, install the **SharpEye Lens M67** (with the two adaptors attached) by mounting it on the housing lens port.

9. When removing the **SharpEye Lens M67** from the housing along with the two adaptors, it can be conveniently stored by attaching it to the **EyeGrabber G7/G9** (Cat. No. 4055), which mounts on Fantasea Flex Arms, thereby making it easily available for future use. For further information, please visit our website at www.fantasea.com/FantaseaEyes

10. After the dive, detach the accessory lens from the housing lens port, including all adaptors, and rinse all lens components in fresh water.

11. Dry and store in a safe protected place.

For further information please contact us at <http://www.fantasea.com/contact> or visit our website at www.fantasea.com.