



Fantasea SharpEye Lens M67

Instruction Manual

The **SharpEye Lens M67** is perfect for shooting close-up images of fish, corals, texture and more. It magnifies the subject and enables the camera to focus on small, nearby objects, creating unique and sharp images.

The **SharpEye Lens M67** is a “wet” lens that fits onto the housing lens port and can be installed and removed during the course of the dive.

Specifications

- Lens Construction: 2 groups, 2 elements
- Focal Length / Diopter: 250mm / +4 (Underwater)
- Mounting: M67 thread mount
- Lens Coating: Multi AR + water repellent coating (external surface)
- Barrel Material: Aluminum with black anodize
- Weight: 138g
- Dimensions: 72 x 22.3mm
- Depth Ratio: 60m/200 feet



Compatibility

The **SharpEye Lens M67** can be mounted on the following housings lens ports:

- Housings with a 67mm thread mount lens port- The **SharpEye Lens M67** can be directly mounted on these housings lens ports and no adaptors are required.
- Canon G10 Housing (WP-DC28)- Mounting the **SharpEye Lens M67** on this housing requires the following adaptor: **EyeDaptor G10-F67** (Cat. No. 4701).
- Canon G9 and G7 Housings (WP-DC21/11)- Mounting **SharpEye Lens M67** on these housings requires the two following adaptors: **EyeDaptor G10-F67** (Cat. No. 4701) and **EyeDaptor G9-G10** (Cat. No.4703).
- FujiFilm F100 and F200 Housings (WP-FXF100/200)- Mounting the **SharpEye Lens M67** on these housings requires the following adaptor: **EyeDaptor FXF100/200-F67** (Cat. No. 4705).

For further information regarding mounting the **SharpEye Lens M67** on other housings, please see- www.fantasea.com/compatibility

Instructions

1. Please use the utmost care and do not use excessive force when assembling and disassembling the different lens accessories, in order not cause any damage to the products.
2. If an adaptor ring is required in order to attach the macro lens to your housing lens port (see *Compatibility* above), attach the adaptor to the macro lens, following the instructions provided with your adaptor.
3. During the dive, install the macro lens by screwing it on to your housing lens port.
4. **Please note that the SharpEye Lens M67 was designed to work underwater only.** Therefore, the lens should only be installed underwater, while letting water enter the gap between the macro lens and the housing lens port. Make sure that there are no air bubbles trapped between the accessory lens and the housing lens port.
5. **When taking photos with the macro lens installed, set your camera focus mode to “MACRO”. Failing to do so will result with blurred images.**
6. The macro lens can be removed and installed repeatedly throughout the course of the dive.
7. When removing the **SharpEye Lens M67** from the housing lens port, it can be secured by attaching it to the **EyeGrabber F67** (Cat. No. 4088), which mounts on Fantasea Flex Arms. For further information, please visit our website at www.fantasea.com\FantaseaEyes .
8. After the dive, detach the macro lens and all adaptors from the housing lens port and rinse all lens components in fresh water.
9. Dry and store in a safe protected place.

For further information please contact us at <http://www.fantasea.com/contact> or visit our website at www.fantasea.com.