

Tray & Handle System Assembly for Fantasea DSLR Camera Housings

Fantasea DSLR Camera Housings come with an easy to assemble Tray & Handle system. Please follow these instructions in order to assemble your system correctly.

The Assembled System



Step 1 - Attaching the Tray to the Camera Housing

1. Hold the Housing (Item #1) so its bottom side is facing up.
2. Position the Tray (Item #2) on top of the housing, so the three screw holes on the Tray are parallel to the three screw holes on the Housing's black attachment plate. Please note that the tray should be positioned in a way that the socket on the tray is

facing down, towards the housing and handles. The conical side of the Tray screw holes should be facing up.

3. Use a Philips screwdriver in order to screw the three screws you have received with the Housing into the three screw holes on the Tray. It's important to tighten the screws only after all three screws are in place.

Step 2 - Attaching the Handles to the Tray

1. Place a Handle (Item #3) on top of the end of the Tray. The Handle and Tray feature sockets that should connect to each other.
2. Position the handle in a comfortable distance from the Housing. Please note that positioning the Handle too close to the Camera Housing will interfere with opening and closing the Housing's buckles. On the other hand, positioning the Handle too far from the Camera Housing might make it difficult to reach the Housing's control buttons while still holding the Handles.
3. Insert the Handle screw (Item #4) from the bottom of the Tray, through the track, into the Handle, and tighten the screw.
4. Do the same for the other Handle on the other side of the Tray.

You can also find these instructions in our Customer Support Section on the website- <http://www.fantasea.com/technical.asp>

For further information please contact us at info@fantasea.com